4STB - OVERDRIVE OPTIONAL RELAY CONTROLLER W/ AUTO RESET

WIRING INSTRUCTIONS

WIRE COLOR	FUNCTION
Blue	Oil pressure switch on side of transmission (either terminal - doesn't matter)
Red	12v+ switched from ignition (fused)
Black	Ground
Yellow	To white wire on the driver's side at rear of transmission (overdrive solenoid)
Green	To momentary button
White	To another prong on momentary button
Purple	To black wire on side of transmission (trans brake solenoid) (trans brake valve body only)

NOTE:

1. TRANSMISSION CASE MUST BE PROPERLY GROUNDED FOR THIS SYSTEM TO OPERATE CORRECTLY.


2. SWITCH CAN BE ANY 2-PRONG SINGLE THROW MOMENTARY SWITCH. A REGULAR ON/OFF TOGGLE SWITCH WILL NOT WORK WITH THIS SYSTEM.

3. RELAY CONTROLLER WITHOUT TRANSBRAKE FEATURE HAVE NO PURPLE WIRE.

FREDDY BROWN PERFORMANCE TRANSMISSIONS

631.242.0008
85 Cleveland Av
Bay Shore, N.Y. 11706
FreddyBrownTransmissions.com

4STB NEUTRAL SAFETY, REVERSE LIGHT, AND TRANS-BRAKE WIRING FOR FACTORY CASE CONNECTOR



FB FREDDY BROWN PERFORMANCE TRANSMISSIONS

631.242.0008
85 Cleveland Av
Bay Shore, N.Y. 11706
FreddyBrownTransmissions.com